



2016-2023 Camaro ISC 3rd Brake Light

Recommended Tools:

- T15 Torx Bit
- Flat Blade Screwdriver
- Trim Removal Tool

Installation:

1. Using a trim tool remove the factory trunk lid liner by removing 7 push-in retainers and the trunk latch cover
2. Disconnect the factory harness from the 3rd brake light by using a flat-blade screwdriver to depress the retainer
 - **Note:** This will require a bit of effort to break the foam tape holding the housing in place
3. Remove the 4 - T15 Torx screws allowing retaining clips to come loose and remove clips
4. With clips removed you can now push the factory 3rd brake light housing from the inside away from the deck lid
 - **Note:** This will require a bit of effort to break the foam tape holding the housing in place
5. Clean the mating surface from any of the foam tape or debris that may be left behind so the new foam adhesive will have a clean mounting surface with the trunk lid
6. With the clean surface, we can take the factory wiring harness and plug it into the 3rd brake light
7. Once connected you can then remove the Red film from the foam adhesive and install the 3rd brake light in the factory location
 - **Note:** When pushing the light in place you will hear a snap sound ensuring proper installation
8. Reinstall the trunk liner to complete the installation