



## 2016-2023 Camaro ISC Rapid Fire 3rd Brake Light Harness

### Recommended Tools:

- Flat Blade Screwdriver
- Trim Removal Tool

### Installation:

1. Using a trim tool remove the factory trunk lid liner by removing 7 push-in retainers and the trunk latch cover (Figure 1)
2. Disconnect the factory harness from the 3rd brake light by using a flat-blade screwdriver to depress the retainer (Figure 2)
3. Install Rapid Fire Harness in line with factory harness to 3rd Brake Light (Figures 3 & 4)
4. Once the harness is clipped back into the factory location mount the module to the trunk lid using double-sided tape (Figures 5 & 6)
5. Reinstall the factory trunk liner back in the factory location to complete the installation



