

62640\_C3174 LS3 with Standard Transmission



Step 1: Rear of transmission must be supported using a suitable jack



Step 2: Remove transmission mount bolts

For Technical Assistance, call Moroso's Tech Line (203)-458-0542, 8:30am-5:00pm Eastern Time MOROSO PERFORMANCE PRODUCTS, INC.

80 CARTER DRIVE GUILFORD, CT 06437 www.moroso.com

62640\_C3174INST





Step 3: Remove transmission crossmember bolts



Step 4: Remove transmission crossmemeber from vehicle







Step 5: Place drive shaft loop around drive shaft







Step 6: Place drive shaft base pate over transmission mount bolts







Step 7: Place ¼" spacers on top of crossmember, one on each side and reinstall crossmember







Step 8: Reinstall remaining crossmember bolts





Step 9: Tighten crossmember mounting bolts



Step 10: Remove support from rear of transmission







Step 11: Reinstall and tighten transmission mount bolts







Step 12: Install and tighten drive shaft hardware, with nuts facing outward on both sides
Installation complete