

PHASTEK

Reverse/Backup LED Bulb Installation

Recommended Tools:

- T15 Torx Bit
- ¼" Ratchet

Installation:

1. Open tailgate (*Figure 1*). This will allow access to Torx screws holding the taillight to the bed.
2. Remove the 2 - T15 Torx screws, there will be 2 for each tail light (*Figure 2*).
3. Grab the tail light towards the outer edge and pull firmly to remove them from the mounting location (*Figure 3 and Figure 4*).
 - a. The first time the lights are removed it will seem a bit tough to remove them from the body retainers.
4. On the backside of the tail light, locate the reverse light harness. This harness will be located in the center of the tail light (*Figure 5*).
5. Twist the socket counterclockwise and remove the socket from the housing (*Figure 6*).
6. With the housing removed, carefully remove the factory incandescent bulb.
 - a. **CAUTION:** If the lights were ON prior to removal, they may be hot.
7. Replace the factory bulb with the Phastek LED bulb and reinstall the socket to the factory location (*Figure 7*).
8. Reinstall the tail light back in the factory location and tighten it in place with the T15 Torx screws.



Figure 1



Figure 2



Figure 3



Figure 4

