



2010-2015 Camaro Wiring Harness Cover

Installation:

1. Raise hood (Figure 1)
2. Open fuse box cover for additional clearance (Figure 2)
3. Place cover under the factory fender lip towards the top of the strut tower (Figure 3)
4. Place the bottom half of the cover past the fuse box (Figure 4)
 - a. **Note:** This will be a tight fit and may require applying pressure on the bottom of the portion of the cover
5. Once the bottom half of the cover is in place, you can slide the cover down to align with the strut tower (Figure 5)
6. Close fuse box cover for final installation (Figure 6)



Figure 1



Figure 2

