

Phastek Performance Reverse LED Harness Installation 6th Gen Camaro #16RVHNS

Kit Contents:

- 1 - Harness for Driver Side Taillight
- 2 - Zip Ties

Recommended Tools:

Plastic Trim Tool
8mm Wrench
Wire Cutter

For Driver side:

1. Open trunk to access trunk cover for taillight
2. Remove 3 push pins and cover on Driver side to access taillight (Figure 1)
3. Remove single plastic push pin on Driver side trunk liner (Figure 2)
4. Pull back liner to access back side of trunk and mounting area for taillight
5. Remove the 3, 8mm nuts holding the taillight to the body (Figure 4 & 5)
6. Once nuts are removed the taillight can be removed
7. Unclip factory connector (Figure 6)
8. Connect supplied harness in line between factory connections (Figure 7)

